

# SafeLine **EVAC**

## ORDERING INFORMATION




Entrance Station  
\*EVAC-ES0101



Floor Station  
\*EVAC-FS0201

# System overview



**LMS - Lift monitoring system (required)**

Power supply and LMS unit. Can be used to send an LMS message through a SafeLine telephone. LMS messages are triggered by events defined in the entrance unit.

**Car station (recommended)**

Microphone and speaker unit for lift car installation. There can only be one car unit in the system.

**Floor station (required)**

Landing unit to be fitted on each point of evacuation, normally one per floor. Maximum 99 floor stations can be used in an EVAC system. Minimum 1 unit is required. Button, illuminated when system is active.

**Entrance station (required)**

The required master unit of the system. All commands and logic is handled by the entrance unit. Max two entry stations can be connected per system.

**Connection board (optional)**

Connection board used to easily retrieve and share supply power and bus signal for entrance, car and floor stations through an RJ45. Speeds up installation and minimizes cabling needed.

**Cabling**

Cables for connecting floor stations in serial in the lift shaft are NOT included in the package. Each connection board however comes with a 5m open-ended cable and 2 contacts for simple wiring between voice stations and the lift shaft.

# SafeLine EVAC ordering information

## EVAC - Standard system, English

Entrance station	Article no.	Price	Piece(s)
EVAC Entrance station 01 - engraved, English text	*EVAC-ES0101 		

Car station	Article no.	Price	Piece(s)
EVAC Car station COP	*EVAC-CS0000 		

Floor station	Article no.	Price	Piece(s)
EVAC Floor station - with button, flush mounted, vandal-proof, English text	*EVAC-FS0201 		

LMS	Article no.	Price	Piece(s)
EVAC PSU & LMS	*EVAC-LMS 		

Connection board	Article no.	Price	Piece(s)
EVAC Connection Board	*EVAC-CB 		

# SafeLine EVAC ordering information

## EVAC - Complete article list


Entrance station	Article no.	Notes	Price	Piece(s)
EVAC Entrance station - with button, no front/key, no back cover	*EVAC-ES0000 	Entry station main unit include: <ul style="list-style-type: none"> <li>• Keyboard, display &amp; PTT button.</li> <li>• Transparent lens.</li> <li>• Mounting plate, stainless steel.</li> <li>• Memory card microSD for logging, 4 GB.</li> <li>• Flat cable RJ45, 5m.</li> </ul>		
EVAC Entrance station 01 - engraved, English text	*EVAC-ES0101 	Entrance station main unit include: <ul style="list-style-type: none"> <li>• Keyboard, display &amp; PTT button.</li> <li>• Front plate engraved w. fire-logo</li> <li>• Keypad, triangular.</li> <li>• Back cover.</li> <li>• Memory card microSD for logging, 4 GB.</li> <li>• Flat cable RJ45, 5m.</li> </ul>		
EVAC Entrance station 02-04 - engraved, no fire-logo  0201 - English text  0301 - German text  0401 - Swedish text	*EVAC-ES0201 *EVAC-ES0301 *EVAC-ES0401  0201 0301 0401 	Entrance station main unit include: <ul style="list-style-type: none"> <li>• Keyboard, display &amp; PTT button.</li> <li>• Front plate engraved, no fire-logo.</li> <li>• Keypad, triangular.</li> <li>• Back cover.</li> <li>• Memory card microSD for logging, 4 GB.</li> <li>• Flat cable RJ45, 5m.</li> </ul> <p>0101 • English text: "Lift Evacuation Intercom", "Talk"</p> <p>0301 • German text: "Sprechanlage für die aufzugsevakuiierung", "Sprechen"</p> <p>0401 • Swedish text: "Brandinterkom för evakuering", "Tala"</p>		
EVAC ES01 Front plate - engraved, English text	*EVAC-PLATE-ES01 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Symbols and text engraved.</li> <li>• English text.</li> <li>• With fire-logo</li> </ul>		
EVAC ES02 Front plate - engraved, no fire-logo English text	*EVAC-PLATE-ES02 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Symbols and text engraved.</li> <li>• English text.</li> <li>• No fire-logo</li> </ul>		
EVAC ES Back cover	*EVAC-BACK-ES01 	<ul style="list-style-type: none"> <li>• Steel Alu/Zink</li> <li>• Used to protect circuit board when flush mounted.</li> <li>• Cannot be used together with a surface mount frame.</li> </ul>		

<b>Entrance station</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC ES Key switch, firemans triangular	*EVAC-KEY-ES01 	<ul style="list-style-type: none"> <li>• Firemans key switch</li> <li>• Two positions: 0° and 90°</li> <li>• Key is not included</li> <li>• Conforms with BSEN60947-3, IEC 60947-3 and VDE 0660 Part 107</li> <li>• N/O</li> </ul>		
EVAC ES Key switch	*EVAC-KEY-ES03 	<ul style="list-style-type: none"> <li>• Firemans key switch</li> <li>• Two positions: 0° and 90°</li> <li>• Key is not included</li> <li>• Conforms with BSEN60947-3, IEC 60947-3 and VDE 0660 Part 107</li> <li>• N/O and N/C</li> </ul>		
EVAC ES Frame	*EVAC-FRAME-ES01 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Used for surface mount installation.</li> <li>• Wall mount screws, 4 pcs.</li> <li>• Cannot be used together with a back cover.</li> </ul>		

<b>Car station</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC Car station COP	*EVAC-CS0000 	<ul style="list-style-type: none"> <li>• Car station with mounting tape</li> </ul>		
EVAC Car station SM	*EVAC-CS0100 	<ul style="list-style-type: none"> <li>• Car station, surface mounted</li> </ul>		

<b>Floor station</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC Floor station - with button, flush mounted  0101 - English text  0301 - German text  0401 - Swedish text	*EVAC-FS0101 *EVAC-FS0301 *EVAC-FS0401  0101 0301 0401 	<ul style="list-style-type: none"> <li>• Floor station unit.</li> <li>• Front plate, engraved</li> <li>• Push-to-talk button, illuminated.</li> <li>• Back cover.</li> <li>• Wall mount screws, 2pcs.</li> </ul> <p>0101 • English text: "Lift Evacuation Intercom"</p> <p>0301 • German text: "Sprechanlage für die aufzugsevakuierung"</p> <p>0401 • Swedish text: "Brandinterkom för evakuering"</p>		
EVAC Floor station 02 - with button, flush mounted, vandal-proof, English text	*EVAC-FS0201 	<ul style="list-style-type: none"> <li>• Floor station unit.</li> <li>• Front plate, engraved, English text</li> <li>• Push-to-talk button, illuminated.</li> <li>• Back cover.</li> <li>• Wall mount screws, 2pcs.</li> <li>• Vandal-proof</li> </ul>		


<b>Floor station</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC Floor station 00 - with button, no front	*EVAC-FS0001 	<ul style="list-style-type: none"> <li>• Floor station unit.</li> <li>• No front plate.</li> <li>• Push-to-talk button, illuminated.</li> <li>• Back cover.</li> <li>• Adhesive tape mount.</li> </ul>		
EVAC FS01 Front plate - engraved, English text	*EVAC-PLATE-FS01 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Engraved, English text.</li> <li>• Assembling components included.</li> </ul>		
EVAC FS02 Front plate - engraved, vandal-proof, English text	*EVAC-PLATE-FS02 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Engraved, English text.</li> <li>• Assembling components included.</li> <li>• Vandal-proof</li> </ul>		
EVAC FS Frame - stainless steel	*EVAC-FRAME-FS01 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Used for surface mount installation.</li> <li>• Front plate screws M4, 2 pcs.</li> <li>• Wall mount screws, 4 pcs.</li> </ul>		
EVAC FS Frame - stainless steel, vandal-proof	*EVAC-FRAME-FS02 	<ul style="list-style-type: none"> <li>• Stainless steel.</li> <li>• Used for surface mount installation.</li> <li>• Front plate screws M4, 2 pcs.</li> <li>• Wall mount screws, 4 pcs.</li> <li>• Vandal-proof</li> </ul>		

<b>LMS</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC PSU & LMS	*EVAC-LMS 	<ul style="list-style-type: none"> <li>• Cable to SL6, 2m.</li> <li>• Wall mount screws, 2pcs.</li> </ul>		


<b>Connection board</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
EVAC Connection Board	*EVAC-CB 	<ul style="list-style-type: none"> <li>• RJ45 connection board for EVAC units.</li> <li>• Cable 5m, open end.</li> <li>• RJ 45 plugs, 2 pcs</li> </ul>		

<b>Asseccories</b>	<b>Article no.</b>	<b>Notes</b>	<b>Price</b>	<b>Piece(s)</b>
Modular plug crimper	*CABLE-MODCRIMP 	<ul style="list-style-type: none"> <li>• Use to attach RJ45 plugs to flat cables for use with connection board.</li> </ul>		
Micro-SD card EVAC, 4 GB, English	*EVAC-SD-EN 	<ul style="list-style-type: none"> <li>• Preloaded English voice messages.</li> </ul>		

## Dimensional sketch, EVAC-PLATE-ES01



## Dimensional sketch, EVAC-PLATE-FS02



## SafeLine Headquarters

Antennvägen 10 · 135 48 Tyresö · Sweden  
Tel.: +46 (0)8 447 79 32 · info@safeline.se  
Support: +46 (0)8 448 73 90

## SafeLine Denmark

Erhvervsvej 19 · 2600 Glostrup · Denmark  
Tel.: +45 44 91 32 72 · info-dk@safeline.se

## SafeLine Norway

Solbråveien 49 · 1383 Asker · Norway  
Tel.: +47 94 14 14 49 · post@safeline.no

## SafeLine Europe

Industrieterrein 1-8 · 3290 Diest · Belgium  
Tel.: +32 (0)13 664 662 · info@safeline.eu  
Support: +32 (0)4 85 89 08 95

## SafeLine Deutschland GmbH

Kurzwannstraße 3 · D-68526 Ladenburg · Germany  
Tel.: +49 (0) 6203 - 840 60 03 · sld@safeline.eu

## SafeLine Elevator Parts UK

3 Evegat Park Barn · Station Road · Smeeth · Ashford · Kent · TN25 6SX · United Kingdom  
Tel.: +44 (0)1303 813414 · info@safeline.uk.com