


OCC manual



Technical data

Size (HxWxD):	122 x 59 x 22mm
Weight:	375 g
Article number:	*OCC

Content

General information	4
Overview	5
OCC card	5
Installation	6
Machine room	6
COP	7
Connect to SafeLine MX2	8
Connect to SafeLine MX3+	9
Connect to SafeLine SL6+	10
Declaration of Conformity	11

General information

This unit was built with state-of-the-art technology and to generally recognised safety related technical standards currently applicable. These installation instructions are to be followed by all people working with the unit, in both installation and maintenance.

It is extremely important that these installation instructions are made available at all times to the relevant technicians, engineers or servicing and maintenance personnel. The basis prerequisite for safe handling and trouble free operation of this system is a sound knowledge of the basic and special safety regulations concerning conveyor technology, and elevators in particular. The unit may only be used for its intended purpose. Note in particular that, no unauthorised changes or additions may be made inside the unit or individual components.

Exclusion of liability

The manufacturer is not liable with respect to the buyer of this product or to third parties for damage, loss, costs or work incurred as a result of accidents, misuse of the product, incorrect installation or illegal changes, repairs or additions. Claims under warranty are likewise excluded in such cases. The technical data is the latest available. The manufacturer accepts no liability arising from printing errors, mistakes or changes.

Declaration of conformity

Download "The declaration of conformity" at our website: www.safeline-group.com

Safety Precautions!


- Only trained professionals, who are authorised to work on the equipment, should install and configure this product.
- This quality product is dedicated for the lift industry. It has been designed and manufactured to be used for its specified purpose only. If it is to be used for any other purpose, SafeLine must be contacted in advance.
- It should not be modified or altered in any way, and should only be installed and configured strictly following the procedures described in this manual.
- All applicable health and safety requirements and equipment standards should be considered and strictly adhered to when installing and configuring this product.
- After installation and configuration this product and the operation of the equipment should be fully tested to ensure correct operation before the equipment is returned to normal use.

Electrical and electronic products may contain materials, parts and units that can be dangerous for the environment and human health. Please inform yourself about the local rules and disposal collection system for electrical and electronic products. The correct disposal of your old product will help to prevent negative consequences for the environment and human health.



Overview




OCC card



Installation

Machine room




Remove 8C cable from REM 5 and connect to the OCC cable.
Machine room



COP

Separate IO8C cable and connet to OCC.


COP



Connect to SafeLine MX2

Complete the OCC connections (see Installation in Machine room and COP).


- The existing alarm button in the lift system will be used as NC.
- It is recommended to set pictogram output as "Strictly EN81-28".
- For programming see MX2 manual.



Connect to SafeLine MX3+

Complete the OCC connections (see Installation in Machine room and COP).


- The existing pictogram in COP will be used.
- The existing alarm button in the lift system will be used as NC.
- It is recommended to set pictogram output as "Strictly EN81-28".
- Parameter *88 must be set to Pictogram output.
- For programming see MX3+ manual.




Connect to SafeLine SL6+

Complete the OCC connections (see Installation in Machine room and COP).


- Connect the OCC cable to SL6+.
- The existing pictogram in COP will be used.
- The existing alarm button in the lift system will be used as NC.
- It is recommended to set pictogram output as "Strictly EN81-28".
- For programming see SL6+ manual.




Machine room



COP



Car top



EU Declaration of Conformity

Product: Cable kit for lift accessories
Type / model: **Connection kit OTIS Rem5**
Article no: *OCC
Manufacturer: SafeLine Sweden AB
Year: 2017

We herewith declare under our sole responsibility as manufacturer that the products referred to above complies with the following EC Directives:

Directives

RoHS 2: 2011/65/EU


Standards applied

EN 50581:2012 RoHS: Technical doc. for assessment of restriction of RoHS

Tyresö, 2017-04-07



Lars Gustafsson,
Technical Manager, R&D , SafeLine Group

**SafeLine Headquarters**

Antennvägen 10 · 135 48 Tyresö · Sweden
Tel.: +46 (0)8 447 79 32 · info@safeline.se
Support: +46 (0)8 448 73 90

SafeLine Denmark

Vallensbækvej 20A, 2. th · 2605 Brøndby · Denmark
Tel.: +45 44 91 32 72 · info-dk@safeline.se

SafeLine Norway

Solbråveien 49 · 1383 Asker · Norway
Tel.: +47 94 14 14 49 · post@safeline.no

SafeLine Europe

Industrieterrein 1-8 · 3290 Diest · Belgium
Tel.: +32 (0)13 664 662 · info@safeline.eu
Support: +32 (0)4 85 89 08 95

SafeLine Deutschland GmbH

Kurzgewannstraße 3 · D-68526 Ladenburg · Germany
Tel./Support: +49 (0)6203 840 60 03 · sld@safeline.eu

SafeLine Group UK

Unit 47 · Acorn Industrial Park · Crayford ·
Kent · DA1 4AL · United Kingdom
Tel.: +44 (0) 1322 52 13 96 · info@safeline-group.uk

SafeLine is a registered trademark of SafeLine Sweden AB. All other trademarks, service marks, registered trademarks, or registered service marks are the property of their respective owners.